

## Procedure to Adjust MO-10 When Tension is on the Vertical Operating Pipe

The motor operator uncoupling bar is designed to slide freely in and out of the slot on the fixed coupling. This signals to the operator the tension has been removed from the vertical operating pipe. In the event the uncoupling bar does not slide freely, the following steps should be taken to prevent injury.

### Verify the outboard bearing is toggled in the intended position.

When operating the switch, the offset bearing should “snap” over dead-center in the closed and open positions. This is also referred to as toggle. This serves as a signal to the operator that the switch is either fully open or closed. This is also a safety feature that insures that the switch is locked in the open and closed positions.




Figure 1

## Uncoupling Bar Does Not Move Freely with Switch Toggled

If the outboard bearing is toggled and the uncoupling bar does not move freely, there is a high probability that the motor operator has over traveled (figure 2). The misalignment causes pressure on the uncoupling bar.

Manually crank the gear train (figure 3) in the opposite direction half turn and check the uncoupling bar freeness. Repeat until the uncoupling bar is free. At this point, adjust the auxiliary cam (figure 4) according to the red decal on the left side door.

With the switch decoupled, electrically operate the motor operator returning to the initial position to verify the coupling slides freely into the slot of the fixed coupling.




Figure 2

Fixed motor coupling should align with pipe coupling.




Figure 4



Figure 3

Manual handle

### Uncoupling Bar Does Not Move Freely with Switch Not Toggled

If the outboard bearing is not toggled, the switch has not traveled enough leaving pressure on the vertical operating pipe. This also will cause pressure on the uncoupling bar.

Verify the outboard bearing stop bolt will allow further travel of the outboard bearing crank (figure 5). Then manually crank the gear train until over-toggle is achieved checking freeness of uncoupling bar. Once free, then adjust the auxiliary cam (figure 4) accordingly, and tighten outboard bearing stop (figure 5).




Figure 5

### Decoupling Tool

If there is a safety concern with pinch points, Pascor Atlantic can provide an uncoupling tool. Insert the uncoupling tool with the hook facing away from the indicator (figure 6) and pull on the uncoupling bar (figure 7). To recouple, push on the coupling bar with the coupling tool until the lockout bar can be installed.



Figure 6



Figure 7

If additional assistance is needed, please call the factory at 276-688-3328,  
Jeremy Moore @ 276-688-2237 or Tim Cook @ 276-688-2216